



| | | | |
|-------------------------------|--------------------------------|---|------------------------|
| DESIGN <i>[Signature]</i> | DRAWN BY <i>RF</i> | DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA | |
| CHECKED <i>[Signature]</i> | APPROVED <i>[Signature]</i> | DRAWING NO. DSI 9172 | REV. A SHEET 1 OF 1 |
| DATE 99.11.02 | | TITLE WEARPAD KITS | SCALE NTS |
| A | 99.11.02 | NEW ISSUE | |

DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS: D206-642

IIN-D350-636

IIN-D058-672

IIN-D315-668

| Qty -105 | Qty -205 | Qty -107 | Qty -207 | Part Number | Description |
|-------------|-------------|-------------|-------------|--------------|-----------------------------------|
| X | | | | DSI 9172-105 | SURFACITE™ WEARPAD KIT |
| | X | | | DSI 9172-205 | STD. TUNGSTEN CARBIDE WEARPAD KIT |
| | | X | | DSI 9172-107 | SURFACITE™ WEARPAD KIT |
| | | | X | DSI 9172-207 | STD. TUNGSTEN CARBIDE WEARPAD KIT |
| | 5 | | 7 | D2648-3 | WEARPAD |
| 5 | | 7 | | D2648-7 | WEARPAD |
| 20 | 20 | 28 | 28 | MS27039-1-08 | SCREWS |
| 20 | 20 | 28 | 28 | AN960JD10L | WASHERS |

NOTES:

- 1) D2648-5 CAN BE REPLACED BY D2648-3.
- 2) IN THE DSI 9172 -105/ -107 KTS, THE D2648-7 WEARPADS REPLACE THE D2648-3 AND D2648-5 WEARPADS SHOWN IN THE INSTALLATION INSTRUCTIONS.
- 3) THE ABOVE KITS CAN BE INSTALLED ON DART 206 A/B, 206L/L1/L3/L4, 407, OH-58 A/A+/C, AS 350/355, AND SA 315B SKIDTUBES ACCORDING TO THE FOLLOWING TABLE:

| KIT | CAN BE INSTALLED ON |
|------------------------------|--|
| DSI 9172-105 DSI 9172-205 | D206-642-111/ -112 D206-642-211/ -212/ -213/ -214 D350-636-011/ -012/ -013/ -014 D315-668-011/ -012 D058-672-011/ -012/ -013/ -014 |
| DSI 9172-107 DSI 9172-207 | D206-642-311/ -312 D206-642-411/ -412 |

- 4) INSTALLATION OF THE DSI 9172 -105 KIT WILL ADD 0.95 lbs (0.43 kg) TO THE WEIGHT OF THE SKIDTUBE.
- 5) INSTALLATION OF THE DSI 9172 -107 KIT WILL ADD 1.33 lbs (0.60 kg) TO THE WEIGHT OF THE SKIDTUBE.